



EZ7300 Microbial Activity ATP Analyser

Proizvod #: EZ7300.XXXXXXXXXX
EUR Cijena: Kontaktirajte nas

Online monitoring of microbial activity in process water and drinking water applications

The first online microbiology analyser complying with standard method ASTM 4012-81

The EZ7300 Series monitor total bacterial and pathogen load in water by measuring portions of ATP (adenosine triphosphate) of any type of microbial microorganism present in the water sample i.e. bacteria (pathogenic and non-pathogenic), microalgae and protozoa. The analyser can be used as an Early Warning System in various applications with focus on water safety, when high ATP values indicate a potential risk in surpassing a threshold value of microorganisms in the past or in the near future.

Determination of total, intracellular and free ATP levels

Contrary to commonly available manual or semi-automated methods, the EZ7300 Series guarantees complete ATP recovery by quantifying different ATP portions in the sample. Operators now can access data on both extracellular (free) and intracellular ATP values, in order to differentiate living biomass from the non-living.

Advanced features

The EZ7300 Online Microbiology Analyser provides results within minutes and an objective, measurable basis for actions against sudden changes in microbial levels in your process:

- Complying with ASTM D4012-81
- Complete ATP recovery
- No bias from the composition of the growth medium such as with plate counting
- Low cost of analysis relative to a large number of results
- Smart automatic features
- Low maintenance, easy replaceable reagent kit
- Multiple stream analysis

There are many additional options available. Please contact Hach for more details.

Alarma:	1 x malfunctioning, 4 x user-configurable, max. 24 VDC/0.5 A, potential free contacts
Analogni izlazi:	Active 4 - 20 mA max. 500 Ohm load, standard 1, max. 8 (option)
Broj uzoraka:	1, 2, 4, or 8
Certificiranja:	CE compliant / UL certified
Demineralised water:	For rinsing
Digital outputs:	Optional: Modbus (TCP/IP, RS485)
Dimenzije (V x Š x D):	690 mm x 465 mm x 330 mm
Earth connection:	Dry and clean earth pole with low impedance (< 1 Ohm) using an earth cable of > 2.5 mm ²
Garancija:	24 mjeseci
Granica detekcije:	≤ 0.05 pg/mL (0.1 pM) ATP
Instrument air:	Dry and oil free according to ISA-S7.0.01-1996 quality standard for instrument air
Interferencija :	High concentrations of Hg ²⁺ , Cu ²⁺ , Zn ²⁺ , Cd ²⁺ , Fe ²⁺ . Total salt concentrations higher than 1 g/L. pH lower than 5.5 and higher than 8.
Kalibracija:	Automatic, 2-point; frequency freely programmable
Kivete:	7 - 10 minutes incl. sample lysis
Klasa zaštite:	Analyser cabinet: IP44 / Panel PC: IP65
Masa:	30 kg
Materijal:	Hinged part: Thermoform ABS, door: PMMA
	Wall section: Galvanised steel, powder coated
Mjerna metoda:	Determination of adenosine triphosphate (ATP) by means of chemiluminescent reaction using luciferin and luciferase, conform with standard method ASTM D4012-81
Mjerni rang:	0.5 - 200 pg/mL
Model:	EZ7300
Napajanje:	100 - 240 VAC, 50/60 Hz
	Max. power consumption: 120 VA
Odvod:	Atmospheric pressure, vented, min. Ø 32 mm
Parametar:	ATP
Pauza:	100 - 240 VAC, 50/60 Hz
Precision:	Better than 4% full scale range for standard test solutions
Protok uzorka:	100 - 300 mL/min
Reagent Requirements:	Keep between 4 - 8 °C during operation, shielded from light. For prolonged storage, store at -20 °C in a dark environment.
Što je u pretincu:	EZ7300 ATP Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 2 x empty 5L Reagent Container with Fittings (NaOH & HCl Solution) and 3 x Screwcap/Fittings/Reference1/Reference2
Temperatura prostora:	7 - 23 °C ±4 °C deviation at 5 - 95% relative humidity (non-condensing)
Temperatura uzorka:	5 - 30 °C
Uzorak: tlak:	Maximum 3 bar for direct injection or by external overflow vessel via the grab sample pump
Validation:	Automatic; frequency freely programmable

Što je u pretincu

EZ7300 ATP Analyser, Instruction Manual, 1 x Double Bit Door Key, 1 x Mounting Brackets, 2 x empty 5L Reagent Container with Fittings (NaOH & HCl Solution) and 3 x Screwcap/Fittings/Reference1/Reference2